
Vermeer





Operation and Safety Video Guidebook

VGJA02-2r2 Revised March, 2015 ORDER NO. 105400-T39

Introduction

This guidebook has been developed to supplement the operation and safety video for Vermeer Tub Grinders. The video and guidebook are one part of a complete set of materials intended to present basic information about safe and productive use of Vermeer Tub Grinders. The video and guidebook are not intended to be a comprehensive course on Tub Grinder operations and safety. Vermeer presents this material only as a reference and guide. Read and study your Tub Grinder Operator's Manual for more details on operations and safety practices.

It is important that everyone who operates or works around the Tub Grinder see the Operation and Safety video and work through this guidebook. Vermeer Manufacturing Company gives you permission to reproduce this guidebook as necessary to inform other workers. Additional copies are also available from your Vermeer dealer.

Be aware that this material is not intended to license or certify any person, nor does registration of attendance or completion of these materials imply that a person is skilled or competent as a Tub Grinder operator.

Copyright © 2001
Vermeer Manufacturing Company
1210 Vermeer Road East
Pella, Iowa 50219-0200

Table of Contents

	Page
Section I - Site Preparation	1
Section I - Answers	10
Section II - Machine Setup	11
Section II - Answers	16
Section III - Grinding Operations	17
Section III - Answers	24
Section IV - Preparation for Transport	25
Section IV - Answers	27
Section V - Optional Loader Setup	28
Section V - Answers	32

Tub Grinder Operations Video Guidebook


INTRODUCTION:


At the end of each video section, the narrator will ask you to stop the tape and do the corresponding section in the Guidebook. You will find those sections following this introduction. The questions will reinforce ideas and information presented in the video.

For most questions, more than one answer is appropriate. Check as many items as necessary to complete the question correctly.


The correct answers are found at the end of each section.


Section I - Site Preparation







Section I - Site Preparation









Section I - Site Preparation




Section I - Site Preparation




Section I - Site Preparation



Section I - Site Preparation



Section I - Site Preparation



Section I - Site Preparation






- 13. As you pull onto a new job site, you must evaluate the conditions and make decisions about where and how to set-up the machine. These decisions will ultimately affect the overall safety conditions on the site. Mark the important considerations:
 - ☐ Check for overhead electric power lines.
 - Position the Tub Grinder as close to the road entrance as possible.
 - Check distances to traveled streets, sidewalks, houses, buildings, playgrounds in order to determine your potential thrown object zone.
 - Check for a firm, level area to position the machine.
 - Position the machine so that the sun will not be in your eyes during operation.





- 14. What means do you have to keep unauthorized people a safe distance from the work area?
 - Put warning cones at the boundary of the thrown object zone - especially where people and vehicles are most likely to approach
 - If people move into the thrown object zone despite the cones tell them personally that they can be injured or killed by ejected material, and instruct them to stay in a designated protected area.
 - Give them a hard hat and safety glasses.
 - Do Nothing.

Section I - Site Preparation



Section I - Site Preparation


Section I - Answers

1. 연 연 연 연 연	2. 1 1 1 1 1 1 1 1 1 1	3. 1	5. 9	6. 8 8 8 8 8 8 8 8	Y	전 전 전
8. 52 1 15. F 16. F 17. T 18. T	9A. 1	9B. 1 0. 9	11. A A B B A A	12. 1	13. Y	14. Y

Section I - Site Preparation


Now restart the video to view Section II.

Section II - Machine Setup





- It is important to raise and secure the Falling Object Canopy over the operator's console area because:
 - It will protect an operator standing at the controls from serious injury due to falling objects.
 - ☐ It will shade the console area.
 - The engine will not start with the canopy down.
 - It provides a guard rail for the top platform.



- 2. Before unfolding the conveyor:
 - Check for power lines that may be too near the conveyor.
 - Be sure workers are out of the way.
 - ☐ Check for straight tracking of the belt.



- 3. The best way to assemble the tub flares for work is to:
 - Lift the flares in place with a crane.
 - Fully raise the tub and bolt the flares in place from the ground.
 - Stand on the Tub platform to pull the flares into place and bolt them.
 - Use a long stepladder.
 - Use the grapple.




4. T or F When working under the tub table, always lift it to the fully open position.

Section II - Machine Set Up



- 5. While the tub is raised, it is convenient to:
 - Check the hammers and teeth for wear.Clean off the frame rails so that the tub can seat tightly when it is lowered later.
 - ☐ Check screen size and change them if necessary.
 - Grease hammermill if necessary.
 - Inspect driveline, hoses and wiring for wear.






- 6. Never engage the hammermill if the tub is raised because:
 - A worker could become entangled in the driveline.
 - A worker could be injured or killed by contacting the rotating hammers.
 - You may get hit by material ejecting out of the exposed hammermill.
 - The hammers may dislodge the screens and fling them out.




- 7A. T or F The TG800 Tub Cover must be fully **closed** before lifting the tub table.
- 7B. T or F The TG400A/TG525 Tub Cover must be fully **open** before lifting the tub table.



Section II - Machine Setup

To prevent vandalism.



Section II - Machine Setup


Section II - Answers

9. प	1. 🗹
10. E	2. T
11. Y	3.
	4. T
	5. 5 5 5 5 5 5 5 5 5 5
	6. E
	7B. T
	9 9 9 9

Section II - Machine Setup

Now restart the video to view Section IV

Section III - Grinding Operations




1. If you engage the clutch to start the rotor and the buzzer sounds, it reminds you that:

The clutch is slipping.

The tub is raised.

The tub cover is open.

The engine is lugging down.




2. During grinding, the operator must continually be alert to prohibited material entering the tub. The best thing to do if you spot some prohibited material going in the tub is to:

Push the emergency stop button.

Shout a warning to everyone.

Honk the horn.

Stop the tub rotation.



3. The designated protected areas are:

Outside the boundary of the Thrown object zone.


☐ Inside the Optional Loader Cab.


At the Operator's console under the Falling Object Canopy.


Inside an enclosed cab of a front end loader or excavator.

On the catwalks of the machine.


Section III - Grinding Operations









Section III - Grinding Operations






Section III - Grinding Operations




ROTATE
OPEN

11. When material has jammed against the Cover and stopped tub rotation, the last procedure to try is:


Reaching in with the grapple to reposition the material.
Reverse tub rotation.
Momentarily opening the Tub Cover.




Section III - Grinding Operations



Section III - Grinding Operations



16. If the rotor assembly or screens become plugged, before clearing plug you should (Rank from 1 - 5).
____ Disengage rotor assembly and allow it to stop turning.
___ Fully raise the tub table.
___ Stop the tub rotation and reduce engine speed to idle.
___ Shut off engine and remove key.
___ Turn off conveyors.



17. If using a front end loader to put material into the tub:

The bucket must have a reach height higher than the top of the tub.

It must have an enclosed cab to protect the operator from ejected objects.

Have a remote control in the cab in order to operate selected Tub Grinder functions, and stop the Tub Grinder when necessary.

You must keep the doors and windows closed to prevent material from hitting you.

Turn on the radio to drown out the Tub Grinder noise.

Section III - Grinding Operations

_	18	Refore leaving the machine for the day:	
	18.	 □ Remove all loose material from around the engine exhaust stack so that it won't smolder and burn. □ Store the optional grapple on the ground or in its cradle. □ Lock up optional loader cab and the ground operator console. □ Store your hard hats. □ Turn off and store the remote control. □ Switch the battery disconnect to "off". 	

Section III - Grinding Operations

Section III - Answers

Section III - Grinding Operations

Now restart the video to view Section IV

Section IV - Preparation for Transport

TC800	1.	Folding and securing the tub flares is required to: Prevent rotation of the tub. Reduce the overall machine width for legal highway use. Aid in cleaning material out of the tub.
	2.	Remove debris from the entire machine before moving onto a public highway: Reduces the chances of a fire occurring around hot brakes. Allows the air brake chambers and brake linkage to operate freely. Improves visibility for the truck driver. Reduces the possibility of debris falling onto the highway or striking a person or

another vehicle.

^	Which of the following items are required before transporting the Tub Grinder on the highway:
	 □ Rotate Tub Cover forward and lock. □ Drain hydraulic and fuel tanks. □ Raise all outriggers and stabilizers. □ Repair and repaint damaged panels. □ Stow safety cones, hard hats, extra parts, and remote control unit in storage box. □ Lower and secure falling object canopy. □ Fully fold up discharge conveyor. □ Raise all folding and pull down steps.

Section IV - Preparation for Transport


Section IV - Answers


|--|

Section IV - Preparation for Transport


Now restart the video to view Section V

Section V - Optional Loader Set Up







2. T or F There are catwalk railings on two levels of the Tub Grinder, which need to be raised and secured during machine setup.





Section V - Optional Loader Set Up






Section V - Optional Loader Set Up





- 7. Before rotating the loader, you should always:
 - Be sure no one is on the loader platforms.
 - Be sure red safety chains are across each side of the lower catwalk access platform opening.
 - Ensure that grapple and loader booms will clear tub and other machine parts.

Section V - Optional Loader Setup



Section V - Optional Loader Set Up

Section V - Answers

1. 년 년 년	2. T	3. T	4. Y Y	5. \	6. Y Y Y	7. 12 1 12 1	
8 Y Y Y Y Y							

Section V - Optional Loader Set Up